



SLX Frequency Codes 08/2011

www.shure.de
www.shure.co.uk
www.shure.nl

P4: 702 - 726 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9	Group 10	Group 11	Group 12	Group 13	Group 14	Group 15	Group 16
1	702,200	703,750	703,650	702,750	703,750	702,100	704,775	702,300	703,000	702,200	710,200	718,200	702,550	702,100	702,700	702,500
2	704,200	705,975	705,650	704,500	705,750	704,025	706,225	704,975	706,025	703,300	711,300	719,300	705,600	704,700	704,700	705,500
3	707,200	707,200	708,650	705,750	708,250	705,500	710,500	706,775	708,000	704,700	712,700	720,700	707,500	710,300	709,450	707,000
4	709,425	708,850	710,875	708,250	711,750	708,500	712,025	709,100	710,300	705,800	713,800	721,800	709,000	712,400	711,500	712,200
5	711,000	710,950	712,450	711,250	714,500	710,100	714,225	710,300	712,225	707,675	715,675	723,675	711,500	714,000	714,500	714,100
6	713,675	712,425	715,125	712,500	715,750	712,025	716,900	712,225	716,000	708,775	716,775		715,100	716,500	716,550	716,400
7	715,575	714,325	717,025	715,250	718,750	713,500	718,500	714,775	717,100				717,000	719,400	719,900	719,500
8	717,050	717,000	718,500	718,750	721,250	717,300	720,775	716,700	719,000				720,000	721,300	722,000	722,200
9	719,150	718,575	720,600	721,250	722,500	725,300	725,300	724,000	720,225				723,500		724,700	
10	720,800	720,800	722,250	723,250	724,250			725,900	722,775				725,900		725,900	
11	722,025	723,800	723,475					724,700								
12	724,250	725,800	725,700													
	Full Range max. # of compatible frequencies (option 1)	Full Range max. # of compatible frequencies (option 2)	Full Range max. # of compatible frequencies (option 3)	France preferred: User Group A (option 1)	France preferred: User Group A (option 2)	France preferred: User Group B (option 1)	France preferred: User Group B (option 2)	France preferred: User Group C (option 1)	France preferred: User Group C (option 2)	Optimized TV channels: TV ch. 50 702-710 MHz	Optimized TV channels: TV ch. 51 710-718 MHz	Optimized TV channels: TV ch. 52 718-726 MHz	Compatible setup for use with PSM400-P3 (P4 > P3)	Compatible setup for use with PSM400-P3 (P4 = P3)	Compatible setup for use with PSM400-HF (P4 > HF)	Compatible setup for use with PSM400-HF (P4 = HF)